


Communication Sheet Cameo ZENIT® W600

Standard DMX



Communication Sheet Cameo Zenit® W600

Wireless Master & Slave



Communication Sheet Cameo ZENIT® W600

W-DMX™ Receiver Function




ZENIT® W600



ZENIT® W600



ZENIT® W600



Transceiver W-DMX™



iDMX® CORE



DMX Light Controller

Communication Sheet Cameo ZENIT® W600

W-DMX™ Receiver Function & iDMX CORE

App control




ZENIT® W600




ZENIT® W600



ZENIT® W600



iDMX® CORE



iDMX® Controller App

Communication Sheet Cameo ZENIT® W600

W-DMX™ Transmitter / Receiver Function

