

TS 100 WW

THEATER SPOT WITH 100W WW LED
DMX CONTROL TABLE



1CH Mode						
Ch.	Function	Values				Sub-Group
1	Dimmer	000	-	255	0% to 100%	Dimmer

3CH Mode						
Ch.	Function	Values				Sub-Group
1	Dimmer	000	-	255	0% to 100%	Dimmer
2	Dimmer fine	000	-	255	0% to 100%	
3	Strobe	000	-	005	Strobe open	Strobe
		006	-	255	Strobe slow -> fast <1Hz - 20Hz	

5CH Mode						
Ch.	Function	Values				Sub-Group
1	Dimmer	000	-	255	0% to 100%	Dimmer
2	Dimmer fine	000	-	255	0% to 100%	
3	Strobe	000	-	005	Strobe open	Strobe
		006	-	255	Strobe slow -> fast <1Hz - 20Hz	
4	Set Dimmer Curve	000	-	005	no function	Set Dimmer Curve
		006	-	063	Linear Dimmer Curve	
		064	-	127	Exponential Dimmer Curve	
		128	-	191	Logarithmic Dimmer Curve	
		192	-	255	S-Curve Dimmer Curve	
5	Device settings	000	-	005	no function	Device settings
		006	-	063	Dimmer Response LED (Hold 3s)	
		064	-	127	Dimmer Response Halogen (Hold 3s)	
		128	-	154	PWM Frequency 650 Hz (Hold 3s)	
		155	-	181	PWM Frequency 1530 Hz (Hold 3s)	
		182	-	208	PWM Frequency 3600 Hz (Hold 3s)	
		209	-	235	PWM Frequency 25 kHz (Hold 3s)	
236	-	255	no function			