

H2 D

DMX-CONTROLLABLE HOUSE LIGHT
WITH DAYLIGHT LED
DMX CONTROL TABLE



1 CH	2 CH	4 CH	Function	CH Mode			Sub-Group	
				Values				
1	1	1	Dimmer	000	-	255	0% to 100%	Dimmer
	2	2	Dimmer fine	000	-	255	0% to 100%	
		3	Strobe functions	000	-	005	Strobe open	Multifunctional Strobe
				006	-	010	Strobe closed	
				011	-	022	Ramp up/down, slow -> fast	
				023	-	033	Ramp up/down random, slow->fast	
				034	-	045	Ramp up, slow -> fast	
				046	-	056	Ramp up random, slow -> fast	
				057	-	068	Ramp down, slow -> fast	
				069	-	079	Ramp down random, slow -> fast	
				080	-	102	Random Strobe effect, slow -> fast	
				103	-	127	Strobe Break effect, 5s.1s (short burst with break)	
				128	-	250	Strobe slow -> fast <1Hz - 20Hz	
				251	-	255	Strobe open	
		4		Device settings (please read remark 1*)	000	-	073	
			074		-	075	Dimmer Response LED (hold 1,5 s)	
			076		-	081	Dimmer Response Halogen (hold 1,5 s)	
			082		-	119	No function	
			120		-	121	PWM frequency 800 Hz (hold 3s)	
			122		-	123	PWM frequency 1200 Hz (hold 3s)	
			124		-	125	PWM frequency 2000 Hz (hold 3s)	
			126		-	127	PWM frequency 3600 Hz (hold 3s)	
			128		-	129	PWM frequency 12 KHz (hold 3s)	
			130		-	131	PWM frequency 25 KHz (hold 3s)	
			132		-	139	No function	
			140		-	141	Display on (hold 3s)	
			142		-	143	Display off (hold 3s)	
			144		-	163	No function	
			164		-	165	Dimmer Curve Linear (hold 3s)	
			166		-	167	Dimmer Curve Exponential (hold 3s)	
			168		-	169	Dimmer Curve Logarithmic (hold 3s)	
			170		-	171	Dimmer Curve S-Curve (hold 3s)	
			172		-	235	No function	
			236		-	237	Reset All Functions (hold 3s)	
			238	-	255	No function		

EN: (1*) After the adjustments have been made, set the value to 000 to avoid disturbance by endless function call.

DE: (1*) Nachdem die Einstellungen vorgenommen wurden, stellen Sie den Wert auf 000 ein, um Störungen durch endlosen Funktionsaufruf zu vermeiden.

FR: (1*) Une fois les ajustements effectués, réglez la valeur sur 000 pour éviter les perturbations par appel de fonction sans fin.

ES: (1*) Después de realizar los ajustes, establezca el valor en 000 para evitar perturbaciones mediante una llamada de función sin fin.

PL: (1*) Po dokonaniu ustawień ustaw wartość na 000, aby uniknąć zakłóceń przez niekończące się wywołanie funkcji.

IT: (1*) Dopo aver effettuato le regolazioni, impostare il valore su 000 per evitare disturbi causati da una chiamata a funzione infinita.