

Q-SPOT 40i

COMPACT IP65 OUTDOOR SPOTLIGHT
WITH 40W RGBA LED IN BLACK / WHITE HOUSING
DMX CONTROL TABLE



2CH Mode					
Ch.	Function	Values			
1	Dimmer	000	-	255	0% to 100%
2	Color Macros	000	-	005	Color off
		006	-	013	Red
		014	-	021	Amber
		022	-	029	Yellow warm
		030	-	037	Yellow
		038	-	045	Green
		046	-	053	Turquoise
		054	-	061	Cyan
		062	-	069	Blue
		070	-	077	Lavender
		078	-	085	Mauve
		086	-	093	Magenta
		094	-	101	Pink
		102	-	109	Warm White
		110	-	117	White
		118	-	125	Cold White
		126	-	127	Color Jumping Stop
128	-	191	Color Jumping Speed slow -> fast / color 1 -> 12		
192	-	255	Color Fading Speed slow -> fast / color 1 -> 12		

Q-SPOT 40i

COMPACT IP65 OUTDOOR SPOTLIGHT
WITH 40W RGBA LED IN BLACK / WHITE HOUSING
DMX CONTROL TABLE



3CH Mode					
Ch.	Function	Values			
1	Dimmer	000	-	255	0% to 100%
2	Strobe	000	-	005	Strobe open
		006	-	255	Strobe slow -> fast <1Hz - 20Hz
3	Color Macros	000	-	005	Color off
		006	-	013	Red
		014	-	021	Amber
		022	-	029	Yellow warm
		030	-	037	Yellow
		038	-	045	Green
		046	-	053	Turquoise
		054	-	061	Cyan
		062	-	069	Blue
		070	-	077	Lavender
		078	-	085	Mauve
		086	-	093	Magenta
		094	-	101	Pink
		102	-	109	Warm White
		110	-	117	White
		118	-	125	Cold White
126	-	127	Color Jumping stop		
128	-	191	Color Jumping speed slow -> fast / color 1 -> 12		
192	-	255	Color Fading speed slow -> fast / color 1 -> 12		

4CH Mode					
Ch.	Function	Values			
1	Red	000	-	255	0% to 100%
2	Green	000	-	255	0% to 100%
3	Blue	000	-	255	0% to 100%
4	Amber	000	-	255	0% to 100%

Q-SPOT 40i

COMPACT IP65 OUTDOOR SPOTLIGHT
WITH 40W RGBA LED IN BLACK / WHITE HOUSING
DMX CONTROL TABLE



9CH Mode					
Ch.	Function	Values			
1	Dimmer	000	-	255	0% to 100%
2	Dimmer fine	000	-	255	0% to 100%
3	Strobe functions	000	-	005	Strobe open
		006	-	010	Strobe closed
		011	-	033	Pulse random slow -> fast
		034	-	056	Ramp up random slow -> fast
		057	-	079	Ramp down random slow -> fast
		080	-	102	Random strobe effect slow -> fast
		103	-	127	Strobe break effect, 5s.....1s (short burst with break)
		128	-	250	Strobe slow -> fast <1Hz - 20Hz
3	Strobe	251	-	255	Strobe open
		000	-	005	Strobe open
3	Strobe	006	-	255	Strobe slow -> fast <1Hz - 20Hz
		000	-	255	0% to 100%
4	Red	000	-	255	0% to 100%
5	Green	000	-	255	0% to 100%
6	Blue	000	-	255	0% to 100%
7	Amber	000	-	255	0% to 100%
8	Color Macros (override RGBA)	000	-	005	Color off
		006	-	013	Red
		014	-	021	Amber
		022	-	029	Yellow warm
		030	-	037	Yellow
		038	-	045	Green
		046	-	053	Turquoise
		054	-	061	Cyan
		062	-	069	Blue
		070	-	077	Lavender
		078	-	085	Mauve
		086	-	093	Magenta
		094	-	101	Pink
		102	-	109	Warm White
		110	-	117	White
		118	-	125	Cold White
126	-	127	Color Jumping stop		
128	-	191	Color Jumping speed slow -> fast / color 1 -> 12		
192	-	255	Color Fading speed slow -> fast / color 1 -> 12		
9	Color Temperature Correction (affects Ch. 5 + 6)	000	-	005	Off
		006	-	255	Cold -> warm