

TRIBAR 100 / 200 IR

DMX CONTROL TABLE



2-CHANNEL-MODE		
CHANNEL	VALUE	FUNCTION
CH1	000 - 255	Master-Dimmer (0 - 100%)
CH2	000 - 255	Colour-Macro
	000 - 036	Red
	037 - 073	Green
	074 - 110	Blue
	111 - 147	Yellow
	148 - 184	Magenta
	185 - 221	Cyan
	222 - 255	White

9-CHANNEL-MODE		
CHANNEL	VALUE	FUNCTION
CH1	000 - 255	Red 1 (0 - 100%)
CH2	000 - 255	Green 1 (0 - 100%)
CH3	000 - 255	Blue 1 (0 - 100%)
CH4	000 - 255	Red 2 (0 - 100%)
CH5	000 - 255	Green 2 (0 - 100%)
CH6	000 - 255	Blue 2 (0 - 100%)
CH7	000 - 255	Red 3 (0 - 100%)
CH8	000 - 255	Green 3 (0 - 100%)
CH9	000 - 255	Blue 3 (0 - 100%)

3-CHANNEL-MODE 1		
CH1	CH2	CH3
000 - 017 PG00	000 - 035 Blackout 036 - 255 Colour Macro	
018 - 035 PG01		
036 - 053 PG02		
054 - 071 PG03		
072 - 089 PG04		
090 - 107 PG05		000 - 010 No Function
108 - 125 PG06	000 - 255 Speed (slow - fast)	011 - 255 Strobe (slow - fast)
126 - 143 PG07		
144 - 161 PG08		
162 - 179 PG09		
180 - 197 PG10		
198 - 215 PG11		
216 - 233 PG12		
234 - 255 Sound Control	000 - 255 Microphone Sensitivity	

3-CHANNEL-MODE 2		
CHANNEL	VALUE	FUNCTION
CH1	000 - 255	Red (0 - 100%)
CH2	000 - 255	Green (0 - 100%)
CH3	000 - 255	Blue (0 - 100%)

12-CHANNEL-MODE												
CH1	CH2	CH3	CH4	CH5	CH6	CH7	CH8	CH9	CH10	CH11	CH12	
000 - 017 PG00	000 - 035 Blackout/ Colour Mix Ch 4 - 12											
018 - 035 PG01	036 - 255 Colour Macro	000 - 010 No Function 011 - 255 Strobe (slow - fast)	Red 1 (0 - 100%)	Green 1 (0 - 100%)	Blue 1 (0 - 100%)	Red 2 (0 - 100%)	Green 2 (0 - 100%)	Blue 2 (0 - 100%)	Red 3 (0 - 100%)	Green 3 (0 - 100%)	Blue 3 (0 - 100%)	
036 - 053 PG02												
054 - 071 PG03												
072 - 089 PG04												
090 - 107 PG05												
108 - 125 PG06												
126 - 143 PG07			000 - 255 Speed (slow - fast)									
144 - 161 PG08												
162 - 179 PG09												
180 - 197 PG10												
198 - 215 PG11												
216 - 233 PG12												
234 - 255 Sound Control	000 - 255 Microphone Sensitivity											