

LUXIS FC

FULL COLOUR LED PAR 200 W RGBALC
DMX CONTROL TABLE



1 CH User Color 1	3 CH RGB	Function	Values	
1	-	Dimmer	000 - 255	0% to 100%
-	1	Red	000 - 255	0% to 100%
	2	Green	000 - 255	0% to 100%
	3	Blue	000 - 255	0% to 100%

3 CH Presets +D	5 CH RGB +D	9 CH Direct +D	Function	Values		Sub-Group
1	1	1	Dimmer	000 - 255	0% to 100%	Dimmer
-	-	2	Multi- functional Strobe	000 - 005	Strobe open	Strobe
				006 - 010	Strobe closed	
				011 - 022	Ramp up/down, slow -> fast	
				023 - 033	Ramp up/down random, slow->fast	
				034 - 045	Ramp up, slow -> fast	
				046 - 056	Ramp up random, slow -> fast	
				057 - 068	Ramp down, slow -> fast	
				069 - 079	Ramp down random, slow -> fast	
				080 - 102	Random Strobe effect, slow -> fast	
				103 - 127	Strobe Break effect, 5s.....1s (short burst with break)	
				128 - 250	Strobe slow -> fast <1Hz - 20Hz	
251 - 255	Strobe open					
-	-	3	Red	000 - 255	0% to 100%	Direct
		4	Green	000 - 255	0% to 100%	
		5	Blue	000 - 255	0% to 100%	
		6	Amber	000 - 255	0% to 100%	
		7	Lime	000 - 255	0% to 100%	
		8	Cyan	000 - 255	0% to 100%	

LUXIS FC

FULL COLOUR LED PAR 200 W RGBALC
DMX CONTROL TABLE



-	2	-	Red	000 - 255	0% to 100%	RGB (Calibrated)
	3		Green	000 - 255	0% to 100%	
	4		Blue	000 - 255	0% to 100%	

LUXIS FC

FULL COLOUR LED PAR 200 W RGBALC
DMX CONTROL TABLE



2	-	-	Color Presets (override RGBALC, Color Temp. Corr.)	000 - 005	Full on	Color Presets
				006 - 009	46 Dark Magenta	
				010 - 013	29 Plasa Red	
				014 - 017	26 Bright Red	
				018 - 021	127 Smokey Pink	
				022 - 025	36 Medium Pink	
				026 - 029	19 Fire	
				030 - 033	135 Deep Golden Amber	
				034 - 037	778 Millennium Gold	
				038 - 041	21 Gold Amber	
				042 - 045	157 Pink	
				046 - 049	110 Middle Rose	
				050 - 053	109 Light Salmon	
				054 - 057	35 Light Pink	
				058 - 061	134 Golden Amber	
				062 - 065	17 Surprise Peach	
				066 - 069	746 Brown	
				070 - 073	105 Orange	
				074 - 077	20 Medium Amber	
				078 - 081	768 Egg Yolk Yellow	
				082 - 085	15 Deep Straw	
				086 - 089	767 Nectarine	
				090 - 093	101 Yellow	
				094 - 097	100 Spring Yellow	
				098 - 101	88 Lime Green	
				102 - 105	121 LEE Green	
				106 - 109	738 Jas Green	
				110 - 113	89 Moss Green	
114 - 117	139 Primary Green					
118 - 121	124 Dark Green					
122 - 125	323 Jade					
126 - 129	354 Special Steel Blue					

LUXIS FC

FULL COLOUR LED PAR 200 W RGBALC
DMX CONTROL TABLE



2	-	-	Color Presets (override RGBALC, Color Temp. Corr.)	130 - 133	116 Medium Blue-Green	Color Presets
				134 - 137	183 Moonlight Blue	
				138 - 141	132 Medium Blue	
				142 - 145	119 Dark Blue	
				146 - 149	716 Mikkel Blue	
				150 - 153	71 Tokyo Blue	
				154 - 157	181 Congo Blue	
				158 - 161	799 Special KH Lavender	
				162 - 165	707 Ultimate Violet	
				166 - 169	343 Special Medium Lavender	
				170 - 173	798 Chrysalis Pink	
				174 - 177	701 Provence	
				178 - 181	797 Deep Purple	
				182 - 185	48 Rose Purple	
				186 - 189	345 Fuchsia Pink	
				190 - 193	795 Magical Magenta	
				194 - 197	128 Bright Pink	
				198 - 201	2 Rose Pink	
				202 - 207	User Color 1	
				208 - 213	User Color 2	
214 - 219	User Color 3					
220 - 225	User Color 4					
226 - 231	User Color 5					
232 - 237	User Color 6					
238 - 243	User Color 7					
244 - 249	User Color 8					
250 - 255	no function					
3	5	9	Delay	000 - 005	No Delay	DMX-Delay
				006 - 255	0,1s - 2,0s	

LUXIS FC

FULL COLOUR LED PAR 200 W RGBALC
DMX CONTROL TABLE



6 Ch 8Bit	9 Ch Direct Control	Function	Values		Sub-Group
-	1	Dimmer	000 - 255	0% to 100%	Dimmer
-	2	Dimmer fine	000 - 255	0% to 100%	

LUXIS FC

FULL COLOUR LED PAR 200 W RGBALC
DMX CONTROL TABLE



1	3	Red	000 - 255	0% to 100%	Direct
2	4	Green	000 - 255	0% to 100%	
3	5	Blue	000 - 255	0% to 100%	
4	6	Amber	000 - 255	0% to 100%	
5	7	Lime	000 - 255	0% to 100%	
6	8	Cyan	000 - 255	0% to 100%	

LUXIS FC

FULL COLOUR LED PAR 200 W RGBALC
DMX CONTROL TABLE



-	9	Device settings	000 - 024	No function	Control
			025 - 025	Record User Color 1 (hold 3s)	
			026 - 026	Record User Color 2 (hold 3s)	
			027 - 027	Record User Color 3 (hold 3s)	
			028 - 028	Record User Color 4 (hold 3s)	
			029 - 029	Record User Color 5 (hold 3s)	
			030 - 030	Record User Color 6 (hold 3s)	
			031 - 031	Record User Color 7 (hold 3s)	
			032 - 032	Record User Color 8 (hold 3s)	
			033 - 073	No function	
			074 - 075	Dimmer Response LED (hold 3s)	
			076 - 077	Dimmer Response Halogen (hold 3s)	
			078 - 081	No function	
			082 - 083	DTW (Redshift) on (hold 1,5 s)	
			084 - 085	DTW (Redshift) off (hold 1,5 s)	
			086 - 097	No function	
			098 - 099	Auto Fan (hold 3s)	
			100 - 101	Fan Off (hold 1,5s)	
			102 - 103	Fan Constant Low (Hold 3s)	
			104 - 105	Fan Constant Medium (Hold 3s)	
106 - 107	Fan Constant High (Hold 3s)				
108 - 119	no function				
120 - 121	PWM 1 (650 Hz) (hold 3s)				

LUXIS FC

FULL COLOUR LED PAR 200 W RGBALC
DMX CONTROL TABLE



-	9	Device settings	122 - 123	PWM 2 (1530 Hz)(hold 3s)	Control
			124 - 125	PWM 3 (3600 Hz)(hold 3s)	
			126 - 127	PWM 4 (12 kHz)(hold 3s)	
			128 - 129	PWM 5 (18,9 kHz)(hold 3s)	
			130 - 131	PWM 6 (25 kHz)(hold 3s)	
			132 - 133	RAW (hold 3s)	
			134 - 135	Factory Calibration (hold 3s)	
			136 - 137	User Calibration (hold 3s)	
			138 - 139	Smart Calibration (Hold 3s)	
			140 - 141	Display on (hold 3s)	
			142 - 143	Display off (hold 3s)	
			144 - 163	No function	
			164 - 165	Dimmer Curve Linear (hold 3s)	
			166 - 167	Dimmer Curve Exponential (hold 3s)	
			168 - 169	Dimmer Curve Logarithmic (hold 3s)	
			170 - 171	Dimmer Curve S-Curve (hold 3s)	
			172 - 255	No function	
			240 - 241	Factory Default (except DMX-Address, DMX-Mode) (hold 3s)	
			242 - 243	No function	
			244 - 245	Default User A (except DMX-Address, DMX-Mode) (hold 3s)	
			246 - 247	Default User B (except DMX-Address, DMX-Mode) (hold 3s)	
248 - 249	Default User C (except DMX-Address, DMX-Mode) (hold 3s)				
250 - 255	No function				

LUXIS FC

FULL COLOUR LED PAR 200 W RGBALC
DMX CONTROL TABLE



7 CH RGB-CCT	9 CH RGB-CCT	10 CH HSI-CCT	Function	Values		Sub-Group
1	1	1	Dimmer	000 - 255	0% to 100%	Dimmer
2	2	2	Dimmer fine	000 - 255	0% to 100%	
-	3	3	Multi- functional Strobe	000 - 005	Strobe open	Strobe
				006 - 010	Strobe closed	
				011 - 022	Ramp up/down, slow -> fast	
				023 - 033	Ramp up/down random, slow->fast	
				034 - 045	Ramp up, slow -> fast	
				046 - 056	Ramp up random, slow -> fast	
				057 - 068	Ramp down, slow -> fast	
				069 - 079	Ramp down random, slow -> fast	
				080 - 102	Random Strobe effect, slow -> fast	
				103 - 127	Strobe Break effect, 5s.....1s (short burst with break)	
				128 - 250	Strobe slow -> fast <1Hz - 20Hz	
251 - 255	Strobe open					
3	4	-	Red	000 - 255	0% to 100%	RGB (Calibrated)
4	5		Green	000 - 255	0% to 100%	
5	6		Blue	000 - 255	0% to 100%	
-	-	4	Hue	000 - 255	0° (red) thru 360°	HSI
		5	Satura- tion	000 - 255	From 0% (white) to 100% pure color	

LUXIS FC

FULL COLOUR LED PAR 200 W RGBALC
DMX CONTROL TABLE



6	7	6	Color Temp. Corr.	000 - 005	off	CTC affects RGB, HSI. RGB - RGB must be 100% HSI - Saturation must be 0%
				006 - 006	Warm white	
				007 - 046	Warm white -> 2700K	
				047 - 047	Bulb white (2700K)	
				048 - 087	2700K -> 3200K	
				088 - 088	Halogen white (3200K)	
				089 - 128	3200K -> 4000K	
				129 - 129	Neutral white (4000K)	
				130 - 169	4000K -> 5600K	
				170 - 170	Studio white (5600K)	
				171 - 210	5600K -> 6500K	
				211 - 211	Daylight white (6500K)	
				212 - 251	6500K -> cold daylight	
252 - 255	Cold daylight					
7	8	7	Tint (affects Color Temp. Corr.)	000 - 000	Off	
				005 - 127	Magenta -> neutral	
				128 - 128	Neutral	
				129 - 255	Neutral -> green	

LUXIS FC

FULL COLOUR LED PAR 200 W RGBALC
DMX CONTROL TABLE



-	-	8	Color Presets (override RGBALC, Color Temp. Corr.	000 - 005	no function	Color Presets
				006 - 009	46 Dark Magenta	
				010 - 013	29 Plasa Red	
				014 - 017	26 Bright Red	
				018 - 021	127 Smokey Pink	
				022 - 025	36 Medium Pink	
				026 - 029	19 Fire	
				030 - 033	135 Deep Golden Amber	
				034 - 037	778 Millennium Gold	
				038 - 041	21 Gold Amber	
				042 - 045	157 Pink	
				046 - 049	110 Middle Rose	
				050 - 053	109 Light Salmon	
				054 - 057	35 Light Pink	
				058 - 061	134 Golden Amber	
				062 - 065	17 Surprise Peach	
				066 - 069	746 Brown	
				070 - 073	105 Orange	
				074 - 077	20 Medium Amber	
				078 - 081	768 Egg Yolk Yellow	
				082 - 085	15 Deep Straw	
				086 - 089	767 Nectarine	
				090 - 093	101 Yellow	
				094 - 097	100 Spring Yellow	
				098 - 101	88 Lime Green	
				102 - 105	121 LEE Green	
				106 - 109	738 Jas Green	
				110 - 113	89 Moss Green	
				114 - 117	139 Primary Green	
				118 - 121	124 Dark Green	
122 - 125	323 Jade					
126 - 129	354 Special Steel Blue					
130 - 133	116 Medium Blue-Green					
134 - 137	183 Moonlight Blue					

LUXIS FC

FULL COLOUR LED PAR 200 W RGBALC
DMX CONTROL TABLE



-	-	8	Color Presets (override RGBALC, Color Temp. Corr.	138 - 141	132 Medium Blue	Color Presets
				142 - 145	119 Dark Blue	
				146 - 149	716 Mikkel Blue	
				150 - 153	71 Tokyo Blue	
				154 - 157	181 Congo Blue	
				158 - 161	799 Special KH Lavender	
				162 - 165	707 Ultimate Violet	
				166 - 169	343 Special Medium Lavender	
				170 - 173	798 Chrysalis Pink	
				174 - 177	701 Provence	
				178 - 181	797 Deep Purple	
				182 - 185	48 Rose Purple	
				186 - 189	345 Fuchsia Pink	
				190 - 193	795 Magical Magenta	
				194 - 197	128 Bright Pink	
				198 - 201	2 Rose Pink	
				202 - 207	User Color 1	
				208 - 213	User Color 2	
				214 - 219	User Color 3	
				220 - 225	User Color 4	
226 - 231	User Color 5					
232 - 237	User Color 6					
238 - 243	User Color 7					
244 - 249	User Color 8					
250 - 255	no function					
000 - 005	0s					
006 - 105	0,1s - 10s (0,1s Steps)					
106 - 214	11s - 119s (1s Steps)					
215 - 232	2m - 4m50s (10s Steps)					
233 - 252	5m - 20m (1m Steps)					
253 - 253	Random 1 fast 0,1 - 1 Sek	Color Crossfade				
254 - 254	Random 2 standard 0,5 - 5 Sek					
255 - 255	Random 3 slow 5 Sek - 380 Sek					
-	-	9	Color Preset Crossfade			

LUXIS FC

FULL COLOUR LED PAR 200 W RGBALC
DMX CONTROL TABLE



-	9	10	Device settings	000 - 024	No function	Control
				025 - 025	Record User Color 1 (hold 3s)	
				026 - 026	Record User Color 2 (hold 3s)	
				027 - 027	Record User Color 3 (hold 3s)	
				028 - 028	Record User Color 4 (hold 3s)	
				029 - 029	Record User Color 5 (hold 3s)	
				030 - 030	Record User Color 6 (hold 3s)	
				031 - 031	Record User Color 7 (hold 3s)	
				032 - 032	Record User Color 8 (hold 3s)	
				033 - 073	No function	
				074 - 075	Dimmer Response LED (hold 3s)	
				076 - 077	Dimmer Response Halogen (hold 3s)	
				078 - 081	No function	
				082 - 083	DTW (Redshift) on (hold 1,5 s)	
				084 - 085	DTW (Redshift) off (hold 1,5 s)	
				086 - 097	No function	
				098 - 099	Auto Fan (hold 3s)	
100 - 101	Fan Off (hold 1,5s)					

LUXIS FC

FULL COLOUR LED PAR 200 W RGBALC
DMX CONTROL TABLE



-	9	10	Device settings	102 - 103	Fan Constant Low (Hold 3s)	Control
				104 - 105	Fan Constant Medium (Hold 3s)	
				106 - 107	Fan Constant High (Hold 3s)	
				108 - 119	no function	
				120 - 121	PWM 1 (650 Hz) (hold 3s)	
				122 - 123	PWM 2 (1530 Hz)(hold 3s)	
				124 - 125	PWM 3 (3600 Hz)(hold 3s)	
				126 - 127	PWM 4 (12 kHz)(hold 3s)	
				128 - 129	PWM 5 (18,9 kHz)(hold 3s)	
				130 - 131	PWM 6 (25 kHz)(hold 3s)	
				132 - 133	RAW (hold 3s)	
				134 - 135	Factory Calibration (hold 3s)	
				136 - 137	User Calibration (hold 3s)	
				138 - 139	Smart Calibration (Hold 3s)	
				140 - 141	Display on (hold 3s)	
				142 - 143	Display off (hold 3s)	
				144 - 163	No function	
				164 - 165	Dimmer Curve Linear (hold 3s)	
				166 - 167	Dimmer Curve Exponential (hold 3s)	
				168 - 169	Dimmer Curve Logarithmic (hold 3s)	
170 - 171	Dimmer Curve S-Curve (hold 3s)					
172 - 255	No function					
-	9	10	Device settings	240 - 241	Factory Default (except DMX-Address, DMX-Mode) (hold 3s)	Control
				242 - 243	No function	
				244 - 245	Default User A (except DMX-Address, DMX-Mode) (hold 3s)	
				246 - 247	Default User B (except DMX-Address, DMX-Mode) (hold 3s)	
				248 - 249	Default User C (except DMX-Address, DMX-Mode) (hold 3s)	
				250 - 255	No function	

LUXIS FC

FULL COLOUR LED PAR 200 W RGBALC
DMX CONTROL TABLE



12 CH 16Bit	16 CH Direct 16Bit	20 CH Full Access	Function	Values		Sub-Group
-	1	1	Dimmer	000 - 255	0% to 100%	Dimmer
-	2	2	Dimmer fine	000 - 255	0% to 100%	
-	3	3	Multi- functional Strobe	000 - 005	Strobe open	Strobe
				006 - 010	Strobe closed	
				011 - 022	Ramp up/down, slow -> fast	
				023 - 033	Ramp up/down random, slow->fast	
				034 - 045	Ramp up, slow -> fast	
				046 - 056	Ramp up random, slow -> fast	
				057 - 068	Ramp down, slow -> fast	
				069 - 079	Ramp down random, slow -> fast	
				080 - 102	Random Strobe effect, slow -> fast	
				103 - 127	Strobe Break effect, 5s.....1s (short burst with break)	
				128 - 250	Strobe slow -> fast <1Hz - 20Hz	
			251 - 255	Strobe open		
1	4	4	Red	000 - 255	0% to 100%	Direct
2	5	5	Red fine	000 - 255	0% to 100%	
3	6	6	Green	000 - 255	0% to 100%	
4	7	7	Green fine	000 - 255	0% to 100%	
5	8	8	Blue	000 - 255	0% to 100%	
6	9	9	Blue fine	000 - 255	0% to 100%	
7	10	10	Amber	000 - 255	0% to 100%	
8	11	11	Amber fine	000 - 255	0% to 100%	
9	12	12	Lime	000 - 255	0% to 100%	
10	13	13	Lime fine	000 - 255	0% to 100%	
11	14	14	Cyan	000 - 255	0% to 100%	
12	15	15	Cyan fine	000 - 255	0% to 100%	

LUXIS FC

FULL COLOUR LED PAR 200 W RGBALC
DMX CONTROL TABLE



		16	Color Temp. Corr.	000 - 005	off	CTC affects Direct. Direct - RGBALC must be 100%
				006 - 006	Warm white	
				007 - 046	Warm white -> 2700K	
				047 - 047	Bulb white (2700K)	
				048 - 087	2700K -> 3200K	
				088 - 088	Halogen white (3200K)	
				089 - 128	3200K -> 4000K	
				129 - 129	Neutral white (4000K)	
				130 - 169	4000K -> 5600K	
				170 - 170	Studio white (5600K)	
				171 - 210	5600K -> 6500K	
				211 - 211	Daylight white (6500K)	
				212 - 251	6500K -> cold daylight	
		252 - 255	Cold daylight			
		17	Tint (affects Color Temp.e Corr.)	000 - 000	Off	Color Presets
				005 - 127	Magenta -> neutral	
				128 - 128	Neutral	
				129 - 255	Neutral -> green	
				000 - 005	no function	
				006 - 009	46 Dark Magenta	
				010 - 013	29 Plasa Red	
				014 - 017	26 Bright Red	
				018 - 021	127 Smokey Pink	
				022 - 025	36 Medium Pink	
				026 - 029	19 Fire	
030 - 033	135 Deep Golden Amber					
18	Color Presets (override RGBALC, Color Temp. Corr.)	034 - 037	778 Millennium Gold			
		038 - 041	21 Gold Amber			
		042 - 045	157 Pink			
		046 - 049	110 Middle Rose			
		050 - 053	109 Light Salmon			
		054 - 057	35 Light Pink			
		058 - 061	134 Golden Amber			

LUXIS FC

FULL COLOUR LED PAR 200 W RGBALC
DMX CONTROL TABLE



				062 - 065	17 Surprise Peach	
				066 - 069	746 Brown	
				070 - 073	105 Orange	
				074 - 077	20 Medium Amber	
				078 - 081	768 Egg Yolk Yellow	
				082 - 085	15 Deep Straw	
				086 - 089	767 Nectarine	
				090 - 093	101 Yellow	
				094 - 097	100 Spring Yellow	
				098 - 101	88 Lime Green	
				102 - 105	121 LEE Green	
				106 - 109	738 Jas Green	
				110 - 113	89 Moss Green	
				114 - 117	139 Primary Green	
				118 - 121	124 Dark Green	
			Color Presets (override RGBALC, Color Temp. Corr.)	122 - 125	323 Jade	Color Presets
				126 - 129	354 Special Steel Blue	
				130 - 133	116 Medium Blue-Green	
				134 - 137	183 Moonlight Blue	
				138 - 141	132 Medium Blue	
				142 - 145	119 Dark Blue	
				146 - 149	716 Mikkel Blue	
				150 - 153	71 Tokyo Blue	
				154 - 157	181 Congo Blue	
				158 - 161	799 Special KH Lavender	
				162 - 165	707 Ultimate Violet	
				166 - 169	343 Special Medium Lavender	
				170 - 173	798 Chrysalis Pink	
				174 - 177	701 Provence	
				178 - 181	797 Deep Purple	
				182 - 185	48 Rose Purple	
				186 - 189	345 Fuchsia Pink	
				190 - 193	795 Magical Magenta	

LUXIS FC

FULL COLOUR LED PAR 200 W RGBALC
DMX CONTROL TABLE



-	-	18	Color Presets (override RGBALC, Color Temp. Corr.)	194 - 197	128 Bright Pink	Color Presets
				198 - 201	2 Rose Pink	
				202 - 207	User Color 1	
				208 - 213	User Color 2	
				214 - 219	User Color 3	
				220 - 225	User Color 4	
				226 - 231	User Color 5	
				232 - 237	User Color 6	
				238 - 243	User Color 7	
				244 - 249	User Color 8	
				250 - 255	no function	
				000 - 005	0s	
				006 - 105	0,1s - 10s (0,1s Steps)	
				106 - 214	11s - 119s (1s Steps)	
-	-	19	Color Presets Crossfade	215 - 232	2m - 4m50s (10s Steps)	Color Cross- fade
				233 - 252	5m - 20m (1m Steps)	
				253 - 253	Random 1 fast 0,1 - 1 Sek	
				254 - 254	Random 2 standard 0,5 - 5 Sek	
				255 - 255	Random 3 slow 5 Sek - 380 Sek	
-	16	20	Device settings	000 - 024	No function	Control
				025 - 025	Record User Color 1 (hold 3s)	
				026 - 026	Record User Color 2 (hold 3s)	
				027 - 027	Record User Color 3 (hold 3s)	
				028 - 028	Record User Color 4 (hold 3s)	
				029 - 029	Record User Color 5 (hold 3s)	
				030 - 030	Record User Color 6 (hold 3s)	
				031 - 031	Record User Color 7 (hold 3s)	
				032 - 032	Record User Color 8 (hold 3s)	
				033 - 073	No function	

LUXIS FC

FULL COLOUR LED PAR 200 W RGBALC
DMX CONTROL TABLE



-	16	20	Device settings	074 - 075	Dimmer Response LED (hold 3s)	Control
				076 - 077	Dimmer Response Halogen (hold 3s)	
				078 - 081	No function	
				082 - 083	DTW (Redshift) on (hold 1,5 s)	
				084 - 085	DTW (Redshift) off (hold 1,5 s)	
				086 - 097	No function	
				098 - 099	Auto Fan (hold 3s)	
				100 - 101	Fan Off (hold 1,5s)	
				102 - 103	Fan Constant Low (Hold 3s)	
				104 - 105	Fan Constant Medium (Hold 3s)	
				106 - 107	Fan Constant High (Hold 3s)	
				108 - 119	no function	
				120 - 121	PWM 1 (650 Hz) (hold 3s)	
				122 - 123	PWM 2 (1530 Hz)(hold 3s)	
				124 - 125	PWM 3 (3600 Hz)(hold 3s)	
				126 - 127	PWM 4 (12 kHz)(hold 3s)	
				128 - 129	PWM 5 (18,9 kHz)(hold 3s)	
				130 - 131	PWM 6 (25 kHz)(hold 3s)	
				132 - 133	RAW (hold 3s)	
				134 - 135	Factory Calibration (hold 3s)	
				136 - 137	User Calibration (hold 3s)	
				138 - 139	Smart Calibration (Hold 3s)	
				140 - 141	Display on (hold 3s)	
				142 - 143	Display off (hold 3s)	
				144 - 163	No function	
				164 - 165	Dimmer Curve Linear (hold 3s)	

LUXIS FC

FULL COLOUR LED PAR 200 W RGBALC
DMX CONTROL TABLE



-	16	20	Device settings	166 - 167	Dimmer Curve Exponential (hold 3s)	Control
				168 - 169	Dimmer Curve Logarithmic (hold 3s)	
				170 - 171	Dimmer Curve S-Curve (hold 3s)	
				172 - 255	No function	
				240 - 241	Factory Default (except DMX-Address, DMX-Mode) (hold 3s)	
				242 - 243	No function	
				244 - 245	Default User A (except DMX-Address, DMX-Mode) (hold 3s)	
				246 - 247	Default User B (except DMX-Address, DMX-Mode) (hold 3s)	
				248 - 249	Default User C (except DMX-Address, DMX-Mode) (hold 3s)	
				250 - 255	No function	