

THUNDERWASH 600 UV

DMX CONTROL TABLE



4 CH Mode						
Ch.	Function	Values				Sub-Group
1	Dimmer	000	-	255	0% to 100%	Dimmer
2	Strobe	000	-	005	Strobe open	Strobe
		006	-	255	Strobe slow -> fast <1Hz - 30Hz	
3	Duration	000	-	255	Flash duration (1ms to 510ms)	
4	Sound (overrides Strobe)	000	-	005	Sound Control OFF (Mic Sensitivity)	Sound
		006	-	255	Sound Control ON Low -> High (Mic Sensitivity)	

2 CH Mode						
Ch.	Function	Values				Sub-Group
1	Dimmer	000	-	255	0% to 100%	Dimmer
2	Strobe	000	-	005	Strobe open	Strobe
		006	-	255	Strobe slow -> fast <1Hz - 30Hz	

1 CH 2 Mode						
Ch.	Function	Values				Sub-Group
1	Dimmer	000	-	255	0% to 100%	Dimmer

1 CH 1 Mode						
Ch.	Function	Values				Sub-Group
1	Strobe	000	-	005	Strobe open	Strobe
		006	-	255	Strobe slow -> fast <1Hz - 30Hz	