

# FLAT PRO FLOOD IP65 TRI

## DMX CONTROL TABLE



| 2-CHANNEL MODE |               |           |                        |
|----------------|---------------|-----------|------------------------|
| <b>CH1</b>     | Master Dimmer | 000 - 255 | Master dimmer (0-100%) |
| <b>CH2</b>     | Colour macros | 000 - 036 | Red                    |
|                |               | 037 - 073 | Green                  |
|                |               | 074 - 110 | Blue                   |
|                |               | 111 - 147 | Yellow (RG)            |
|                |               | 148 - 184 | Magenta (RB)           |
|                |               | 185 - 221 | Cyan (GB)              |
|                |               | 222 - 255 | White (RGB)            |

| 3-CHANNEL 1 MODE |               |           |                                     |
|------------------|---------------|-----------|-------------------------------------|
| <b>CH1</b>       | Master Dimmer | 000 - 255 | Master dimmer (0-100%)              |
| <b>CH2</b>       | Stroboscope   | 000       | No function                         |
|                  |               | 001 - 225 | Strobe (speed 0-100%, 1 Hz - 20 Hz) |
| <b>CH3</b>       | Colour Macros | 000 - 004 | Blackout                            |
|                  |               | 005 - 015 | Red                                 |
|                  |               | 016 - 026 | Green                               |
|                  |               | 027 - 037 | Blue                                |
|                  |               | 038 - 048 | Yellow (RG)                         |
|                  |               | 049 - 059 | Magenta (RB)                        |
|                  |               | 060 - 070 | Cyan (GB)                           |
|                  |               | 071 - 080 | White (RGB)                         |
|                  | Program       | 081 - 150 | Colour change (speed slow - fast)   |
|                  |               | 151 - 255 | Colour fading (speed slow - fast)   |

| 3-CHANNEL 2 MODE |       |           |                |
|------------------|-------|-----------|----------------|
| <b>CH1</b>       | Red   | 000 - 255 | Red (0-100%)   |
| <b>CH2</b>       | Green | 000 - 255 | Green (0-100%) |
| <b>CH3</b>       | Blue  | 000 - 255 | Blue (0-100%)  |

| <b>6-CHANNEL MODE</b> |               |           |                                       |
|-----------------------|---------------|-----------|---------------------------------------|
| <b>CH1</b>            | Master Dimmer | 000 - 255 | Master dimmer (0-100%)                |
| <b>CH2</b>            | Stroboscope   | 000       | No function                           |
|                       |               | 001 - 225 | Strobe (speed 0 - 100%, 1 Hz - 20 Hz) |
| <b>CH3</b>            | Dimmer        | 000 - 255 | Red (0-100%)                          |
| <b>CH4</b>            | Dimmer        | 000 - 255 | Green (0-100%)                        |
| <b>CH5</b>            | Dimmer        | 000 - 255 | Blue (0-100%)                         |
| <b>CH6</b>            | Colour macros | 000 - 004 | Blackout / colour mix CH3 - CH5       |
|                       |               | 005 - 015 | Red                                   |
|                       |               | 016 - 026 | Green                                 |
|                       |               | 027 - 037 | Blue                                  |
|                       |               | 038 - 048 | Yellow (RG)                           |
|                       |               | 049 - 059 | Magenta (RB)                          |
|                       |               | 060 - 070 | Cyan (GB)                             |
|                       |               | 071 - 080 | White (RGB)                           |
|                       | Program       | 081 - 150 | Colour change (speed slow - fast)     |
|                       |               | 151 - 255 | Colour fading (speed slow - fast)     |