

STUDIO PAR TW G2

LED PAR SPOTLIGHT
WITH 12 X 3-IN-1 TUNABLE WHITE LED
DMX CONTROL TABLE



1 Ch Dim (CCT Preset)	2 Ch CCT	Function	Values			
1	1	Dimmer	000	-	255	0% to 100%
	2	CCT	000	-	006	Warm white
			007	-	046	Warm white -> 2700K
			047	-	047	Bulb White (2700K)
			048	-	087	2700K -> 3200K
			088	-	088	Halogen White (3200K)
			089	-	128	3200K -> 4000K
			129	-	129	Neutral White (4000K)
			130	-	169	4000K -> 5600K
			170	-	170	Studio-White (5600K)
			171	-	210	5600K -> 6500K
			211	-	211	Daylight White (6500K)
			212	-	254	6500K -> Cold Daylight
			255	-	255	Cold Daylight

D5 CH 8 Bit	D4 CH Strobe CCT	Function	Values			
1	1	Dimmer	000	-	255	0% to 100%
	2	Multifunctional Strobe	000	-	005	Strobe open
			006	-	010	Strobe closed
			011	-	022	Ramp up/down, slow -> fast
			023	-	033	Ramp up/down random, slow->fast
			034	-	045	Ramp up, slow -> fast
			046	-	056	Ramp up random, slow -> fast
			057	-	068	Ramp down, slow -> fast
			069	-	079	Ramp down random, slow -> fast
			080	-	102	Random Strobe effect, slow -> fast
			103	-	127	Strobe Break effect, 5s.....1s (short burst with break)
			128	-	250	Strobe slow -> fast <1Hz - 20Hz
			251	-	255	Strobe open

STUDIO PAR TW G2

LED PAR SPOTLIGHT
WITH 12 X 3-IN-1 TUNABLE WHITE LED
DMX CONTROL TABLE



2		Amber	000	-	255	0% to 100%
3		Warm White	000	-	255	0% to 100%
4		Cold White	000	-	255	0% to 100%
	3	CCT	000	-	006	Warm white
			007	-	046	Warm white -> 2700K
			047	-	047	Bulb White (2700K)
			048	-	087	2700K -> 3200K
			088	-	088	Halogen White (3200K)
			089	-	128	3200K -> 4000K
			129	-	129	Neutral White (4000K)
			130	-	169	4000K -> 5600K
			170	-	170	Studio White (5600K)
			171	-	210	5600K -> 6500K
			211	-	211	Daylight White (6500K)
			212	-	254	6500K -> Cold Daylight
			255	-	255	Cold Daylight
5	4	DMX Delay	000	-	005	No Delay
			006	-	255	0,1s - 2,0s

3 CH AwWcW	Function	Values				
1	Amber	000	-	255	0% to 100%	
2	Warm White	000	-	255	0% to 100%	
3	Cold White	000	-	255	0% to 100%	

8 CH 16Bit	11 CH Full Access	Function	Values				
1	1	Dimmer	000	-	255	0% to 100%	
2	2	Dimmer fine	000	-	255	0% to 100%	
	3	Multifunctional Strobe	000	-	005	Strobe open	
			006	-	010	Strobe closed	
			011	-	022	Ramp up/down, slow -> fast	
			023	-	033	Ramp up/down random, slow->fast	
			034	-	045	Ramp up, slow -> fast	
			046	-	056	Ramp up random, slow -> fast	
			057	-	068	Ramp down, slow -> fast	
			069	-	079	Ramp down random, slow -> fast	
			080	-	102	Random Strobe effect, slow -> fast	

STUDIO PAR TW G2

LED PAR SPOTLIGHT
WITH 12 X 3-IN-1 TUNABLE WHITE LED
DMX CONTROL TABLE



	3	Multifunctional Strobe	103	-	127	Strobe Break effect, 5s.....1s (short burst with break)
			128	-	250	Strobe slow -> fast <1Hz - 20Hz
			251	-	255	Strobe open
3	4	Amber	000	-	255	0% to 100%
4	5	Amber fine	000	-	255	0% to 100%
5	6	Warm White	000	-	255	0% to 100%
6	7	Warm White fine	000	-	255	0% to 100%
7	8	Cold White	000	-	255	0% to 100%
8	9	Cold White fine	000	-	255	0% to 100%
	10	CCT	000	-	005	Off
			006	-	006	Warm White
			007	-	046	Warm white -> 2700K
			047	-	047	Bulb White (2700K)
			048	-	087	2700K -> 3200K
			088	-	088	Halogen White (3200K)
			089	-	128	3200K -> 4000K
			129	-	129	Neutral White (4000K)
			130	-	169	4000K -> 5600K
			170	-	170	Studio-White (5600K)
			171	-	210	5600K -> 6500K
			211	-	211	Daylight White (6500K)
			212	-	254	6500K -> Cold Daylight
			255	-	255	Cold Daylight

STUDIO PAR TW G2

LED PAR SPOTLIGHT
WITH 12 X 3-IN-1 TUNABLE WHITE LED
DMX CONTROL TABLE



			000	-	073	No function
			074	-	075	Dimmer Response LED (hold 1,5s)
			076		077	Dimmer Response Halogen (hold 1,5s)
			078	-	081	No function
			082	-	083	Redshift on (hold 1,5s)
			084	-	085	Redshift off (hold1,5s)
			086	-	097	No function
			098	-	099	Silent Fan (hold 3s)
			100	-	101	Auto Fan (hold 3s)
			102	-	103	Fan Off (hold 3s)
			104	-	119	No function
			120	-	121	PWM 1 (650 Hz) (hold 3s)
			122	-	123	PWM 2 (1530 Hz)(hold 3s)
			124	-	125	PWM 3 (3600 Hz)(hold 3s)
	11	Device Settings				

STUDIO PAR TW G2

LED PAR SPOTLIGHT
WITH 12 X 3-IN-1 TUNABLE WHITE LED
DMX CONTROL TABLE



11	Device Settings	126 - 127	PWM 4 (12000 Hz)(hold 3s)
		128 - 129	PWM 5 (18900 Hz)(hold 3s)
		130 - 131	PWM 6 (25000 Hz)(hold 3s)
		132 - 133	RAW (hold 3s)
		134 - 135	User Calibrated (hold 3s)
		136 - 139	No function
		140 - 141	Display on (hold 3s)
		142 - 143	Display off (hold 3s)
		144 - 163	No function
		164 - 165	Dimmer Curve Linear (hold 3s)
		166 - 167	Dimmer Curve Exponential (hold 3s)
		168 - 169	Dimmer Curve Logarithmic (hold 3s)
		170 - 171	Dimmer Curve S-Curve (hold 3s)
		172 - 239	No function
		240 - 241	Factory Default set (except DMX-Address, DMX-Mode) (hold 3s)
		242 - 243	No function
		244 - 245	Default A-User set (except DMX-Address, DMX-Mode) (hold 3s)
		246 - 247	Default B-User set (except DMX-Address, DMX-Mode) (hold 3s)
		248 - 249	Default C-User set (except DMX-Address, DMX-Mode) (hold 3s)
		250 - 255	No function