

# Cameo ZENIT® W600-D

## DMX CONTROL TABLE



1-CHANNEL-MODE					
Channel	Function	Values			Description
1	Dimmer	000	-	255	Dimmer 0 - 100%

2-CHANNEL-MODE					
Channel	Function	Values			Description
1	Dimmer	000	-	255	Dimmer 0 - 100%
2	Dimmer Fine	000	-	255	Dimmer Fine 0 - 100%

3-CHANNEL-MODE					
Channel	Function	Values			Description
1	Dimmer	000	-	255	Dimmer 0 - 100%
2	Multifunctional Strobe	000	-	005	Strobe open
		006	-	010	Strobe closed
		011	-	033	Pulse Random, slow -> fast
		034	-	056	Ramp up Random, slow -> fast
		057	-	079	Ramp down Random, slow -> fast
		080	-	102	Random Strobe Effect, slow -> fast
		103	-	127	Strobe Break Effekt, 5s.....1s (Short burst with break)
		128	-	250	Strobe slow -> fast (1Hz - 20Hz)
		251	-	255	Strobe open
3	Strobe Duration	000	-	255	Flash Duration 1% - 100% (only affects Channel 2 value 128 - 250)

4-CHANNEL-MODE					
Channel	Function	Values			Description
1	Dimmer	000	-	255	Dimmer 0 - 100%
2	Multifunctional Strobe	000	-	005	Strobe open
		006	-	010	Strobe closed
		011	-	033	Pulse Random, slow -> fast
		034	-	056	Ramp up Random, slow -> fast
		057	-	079	Ramp down Random, slow -> fast
		080	-	102	Random Strobe Effect, slow -> fast
		103	-	127	Strobe Break Effekt, 5s.....1s (Short burst with break)
		128	-	250	Strobe slow -> fast (1Hz - 20Hz)
		251	-	255	Strobe open
3	Dimmer Curves	000	-	005	no function
		006	-	063	Linear Dimmer Curve
		064	-	127	Exponential Dimmer Curve
		128	-	191	Logarithmic Dimmer Curve
		192	-	255	S-Curve Dimmer Curve

4	Device Settings	000	-	005	no function
		006	-	127	Dimmer Response LED (hold 5s)
		128	-	191	Dimmer Response Halogen (hold 5s)
		192	-	200	Fan Auto (hold 5s)
		201	-	209	Fan Max (hold 5s)
		210	-	218	Fan Silent (hold 5s)
		219	-	223	LED Frequency 800 Hz (hold 5s)
		224	-	228	LED Frequency 1200 Hz (hold 5s)
		229	-	233	LED Frequency 2000 Hz (hold 5s)
		234	-	238	LED Frequency 3600 Hz (hold 5s)
		239	-	243	LED Frequency 12 kHz (hold 5s)
		244	-	248	LED Frequency 25 kHz (hold 5s)
		249	-	255	no function

6-CHANNEL-MODE					
Channel	Function	Values			Description
1	Dimmer	000	-	255	Dimmer 0 - 100%
2	Dimmer Fine	000	-	255	Dimmer Fine 0 - 100%
3	Multifunctional Strobe	000	-	005	Strobe open
		006	-	010	Strobe closed
		011	-	033	Pulse Random, slow -> fast
		034	-	056	Ramp up Random, slow -> fast
		057	-	079	Ramp down Random, slow -> fast
		080	-	102	Random Strobe Effect, slow -> fast
		103	-	127	Strobe Break Effekt, 5s.....1s (Short burst with break)
		128	-	250	Strobe slow -> fast (1Hz - 20Hz)
251	-	255	Strobe open		
4	Strobe Duration	000	-	255	Flash Duration 1% - 100% (only affects Channel 3 value 128 - 250)
5	Dimmer Curves	000	-	005	no function
		006	-	063	Linear Dimmer Curve
		064	-	127	Exponential Dimmer Curve
		128	-	191	Logarithmic Dimmer Curve
		192	-	255	S-Curve Dimmer Curve

6	Device Settings	000	-	005	no function
		006	-	127	Dimmer Response LED (hold 5s)
		128	-	191	Dimmer Response Halogen (hold 5s)
		192	-	200	Fan Auto (hold 5s)
		201	-	209	Fan Max (hold 5s)
		210	-	218	Fan Silent (hold 5s)
		219	-	223	LED Frequency 800 Hz (hold 5s)
		224	-	228	LED Frequency 1200 Hz (hold 5s)
		229	-	233	LED Frequency 2000 Hz (hold 5s)
		234	-	238	LED Frequency 3600 Hz (hold 5s)
		239	-	243	LED Frequency 12 kHz (hold 5s)
		244	-	248	LED Frequency 25 kHz (hold 5s)
		249	-	255	no function